


TORNADO FLAMER

SF-180

USER MANUAL



1	PRODUCT INTRODUCTION	A3
1.1	PRODUCT OVERVIEW	A3
1.2	BOTTOM RACKET INSTALLATION	A4
1.3	PRODUCT ACCESSORIES	A4
1.4	FUEL ALLOWED	A4
1.5	PRODUCT FEATURE	A5
2	TECHNICAL PARAMETERS	A5
3	BACK PANEL GUIDE	A7
3.1	BACK PANEL INTRODUCTION	A7
4	INTERFACE	A8
4.1	LED DISPLAY AREA	A8
4.2	MAIN INTERFACE	A8
4.3	ALERT MESSAGE	A9
4.4	INTERFACE SETUP	A9
4.5	ADVANCED INTERFACE	A10
5	OPERATION GUIDE	A11
5.1	SAFETY WARNING	A11
5.2	SAFETY DISTANCE IN WINDY ENVIRONMENT	A12
5.3	FAST OPERATION GUIDE	A13
5.4	FIRING ANGLES	A14
5.5	DRIVEN TIME	A15
6	CONTROL OF TORNADO FLAMER	A15
6.1	SIMPLE IGNITION SEQUENCE LIST	A15
6.2	STEP IGNITION SEQUENCE LIST	A16
6.3	WAVE SEQUENCE LIST	A17
6.4	ADDITIONAL SEQUENCE LIST	A18
7	DMX CONTROL	A18
7.1	ANGLE SETUP	A18
7.2	SPEED SETUP	A19
7.3	IGNITION ON/OFF	A19
7.4	DURATION SETUP	A20
7.5	FIRING SEQUENCE SELECTION	A20
7.6	PUMP WORKING MODE SETUP	A20
7.7	DMX CONTROL	A21
7.7.1	EXAMPLE OF DMX CONTROL	A21
7.7.2	EXAMPLE OF WAVE SEQUENCE	A21
7.7.3	EXAMPLE OF FIXED DURATION	A22
8	HOW TO OPERATE FLAME MACHINE WITH CONSOLE CT-05	A22
8.1	CT-05 INTRODUCTION	A22
8.2	SELECT FLAME MACHINE	A23
8.3	SELECT SHOOTING SERIAL NUMBER	A23
8.4	EDIT THE FILE	A24
9	WARRANTY INSTRUCTIONS	A24
10	WARRANTY CARD	A25

★ Please read this manual carefully before operating this product.

★ Warranty card attached in the manual, please keep it well.

**WARNING**

Unauthorized repair are prohibited, it may cause serious incident.

**WARNING**

Make sure power supply is consistent with the rated voltage of the equipment, and the socket must be well grounded. Unplug and turn off the machine when not in use.

**WARNING**

Before connecting the power cable, communication DMX cable should be well connected and ensure the command keeps at firing OFF status. And safety lock stays at test mode.

**WARNING**

The device can only be placed horizontally. Safety distances are marked on the device (at least 5m in all projection directions, at least 15m to the other sides of the device).

**WARNING**

After turning on the device, no person allows to stay in the danger area. Ensure all persons that are part of the show are informed about the safety distance, risks and functions of the device.

**WARNING**

Always have a CO2 fire extinguisher and an extinguishing blanket in case of need.

**WARNING**

If there is any doubt as to the safety operation of the device in any circumstances, the device should be taken out of service immediately. Be sure the device is in good operating condition before use. If it fails to fire correctly, immediately shut down and check it accordingly.

**WARNING**

Be sure to use high quality flame fluid, otherwise, it is easily led to failure or danger. Be careful when refilling the flame fluid tank. Please keep flame fluid away from heat source, sparks, fire or other possibility of ignition. Do not smoke!

⚠ WARNING

The operator responsible for the control of TORNADO FLAMER must always have a clear view of the device, so that he/she can stop the show immediately when there is danger. The main AC power switch should near operator. So that operator can turn off the power of all devices in case of abnormal.

⚠ WARNING

The device shall not be altered and applied to other use purpose.

⚠ WARNING

Notes for use of Battery power supply: TORNADO FLAMER SF-180 with stable internal circuit design, please support SF-180 with battery voltage higher than 12V. The driving speed of motor won't change because of the decrease of battery power supply.

Battery options: 12V lead-acid battery (above 30AH, with more than 24h standby). For Lithium battery, please use battery with output above 30A.

Socket type: NEUTRIK-NL4FX, 4 pin sound couplers (1+ connect 12V anode, 1- connect 12V cathode).

Connecting power cables should above 14AWG.

FOREWORD

Thanks for choosing SPARK FABRICA TORNADO FLAMER SF-180. Please read following manual carefully and completely before operating this product. Operate according to instructions is very important for safety, and can elongate the service life of the machine.

Strictly follow the instruction in the manual when operate TORNADO FLAMER SF-180. If you have any doubts, please contact SPARK FABRICA by marketing@sparkfabrica.com.

We assume the person who use or come in contact with the device are familiar with how the device should be handled. This includes proper use, maintenance and repair of the machine as defined in this user manual.

DISCLAIMER

SPARK FABRICA excludes liability for unsafe situations, accidents and damages resulting from:


1. Ignoring warnings or regulations as shown on TORNADO FLAMER or this manual.
2. Use for other applications or circumstances other than those indicated herein.
3. Changes to the TORNADO FLAMER including use of non-original spare parts.
4. Removed safety cover without authorization from SPARK FABRICA
5. Use this machine by unqualified or untrained personnel! 6 Improper use of machine

1 PRODUCT INTRODUCTION

This product belongs to special effects equipment, only for professional use.

This product its special fx equipment project flames, it can be controllled by DMX to display 88 flame combinations.This product is widely used in weddings, concerts, sports events, event meetings and so on.Stimulate your interest and light up your activity.


1.1 PRODUCT OVERVIEW



- 1 Handle
- 2 Firing Head
- 3 Stop rod
- 4 Fuel Bottle Area
- 5 Top Panel
- 6 Control Panel
- 7 Safety Loop

1.2 BOTTOM RACKET INSTALLATION

Connection dimension diagram of bottom bracket of the flamer.



1.3 PRODUCT ACCESSORIES

1.6 Meter Power Plug or 3 Meters Power Pair Cable
3 Meters DMX Pair Cable
Safety Rope
User Manual

NOTICE

Open the package carefully and check to make sure the goods are in good condition.

1.4 FULE ALLOWED

ISOPAR

1.5 FUNCTIONAL CHARACTERISTICS


- ★ Compact pumping system ensure compact size of machine.
- ★ Double electromagnetic valves design for additional safety.
- ★ Tilt protection, the tilt sensor will be activated when machine slant Over 45° .
- ★ Unique safety lock design, device can't firing when locked, avoid spurious triggering.
- ★ Intelligent control system: pressure monitoring, safety warning, no fuel alarming, system failure warning etc..
- ★ High performance nozzle, reliable and durable.
- ★ High-accuracy swiveling head driving and controlling system, allows for fast and precise flame bursts.
- ★ Strengthened and rustproof metal panel, water-proof design.
- ★ Neutrik PowerCON TRUE1 and DMX socket.
- ★ Fitted with fireworks ignition signal port, can be triggered by fireworks ignition.
- ★ Flame effects up to 8-10m (no wind), with 210° (±105°) swiveling angles.
- ★ As much as 88 preset flame sequences are available. It is easier and stable to running the TORNADO FLAMER when controlled by SPARK FABRICA Pyro Sim Console CT-05

2 TECHNICAL PARAMETERS

Identification	Manufacturer	SPARK FABRICA
	Name	TORNADO FLAMER
	Model	SF-180
AC Power	Input Voltage & Frequency	100-120V , 60HZ
	Input Voltage & Frequency	200-240V , 50HZ
	Power	550W
	Power Input Connector	SEETRONIC
	Power Output Connector	SEETRONIC
Interface Type	DMX Signal Interface	3 PIN / 5PIN Double DMX Interface
	Signal Interface	3 PIN / 5PIN Double DMX Interface
	Signal Interface	15V-24V Fireworks Ignition Signal Interface
Waterproof	Waterproof	IP55
Hopper	Fuel Bottle Capacity	10L
Control	Control Protocol	DMX-512
	Control Mode	Standard DMX Signal Control
	Effect Angles	210° (±105°)
Accessory	Power Plug	√ SEETRONIC (1.6Meter)
	DMX Cable	√ 3Meter
	Power Cable	√ 3Meter
	Safety Loop	√
	Safety Rope	√
	Update Box	Optional
Oil Consumption	Firing Head	60ml/s
Ignition	Ignition Mode	High Voltage Electronic Ignition
Weight	Net Weight (No Fuel)	29kg
	Gross Weight	50kg
Dimensions	Machine Dimensions - L*W*H	630mm*363mm*373mm
	1 Unit Flight case Size - L*W*H	865mm*430mm*500mm
Fuel Oil	Kind	ISOPAR

3 BACK PANEL GUIDE

3.1 BACK PANEL INTRODUCTION



4 INTERFACE

4.1 LED DISPLAY AREA

-
Parameter Down

MENU


Switch interface to setup parameter.

RX

Radio receiving (reserved).

DMX

DMX signal. Flash means DMX signal available, otherwise no DMX signal



LCD DISPLAY AREA

+
Parameter Up

ENTER

Confirm and save parameters (screen will flash when parameters saved)

PUMP

Light on when pump is running

ERR

Light on when there is an error.


NOTICE

Screen display will switch to main interface if don't press button for a long time.

4.2 MAIN INTERFACE

DMX Address

Mode



Pressure 0

(e.g. 100=10bar); V: 15.6 means

DMX Address

Mode



Pressure 0

(e.g. 100=10bar); V: 15.6 means

Voltage

Internal Voltage Is 15.6v.

4.3 ALERT MESSAGE

ALERT MESSAGE		EXPLANATION
E0	Test Mode	Safety lock located at TEST MODE.
	Factory Mode	DMX signal blocked in factory mode.
	Invert ON	When turned on, all angles will be mirrored.
	Motor Disable	When turned on, the position of the firing head should be moved or set manually, and the motor of firing head will be disable (The flamer should be restarted before it takes effect.)
E1 Pressure Err		Pressurize for about 13s, pressure value failed to reach 100%, system will report E1. Possible fault: No fuel, pump failure, pipeline problem etc.
E2 P Relief Err		Pipeline can't release pressure leads to pressure relief error. Possible fault: pressure release valve failure, pipeline problem or control system problem etc.
E3 Motor Err		Possible fault: swiveling nozzle stuck, motor failure etc.
E4 ExtIgnition ON		When Ext Ignite is ON, device will pressurize automatically when switch safety lock to USER MODE; decompression when switch to TEST MODE. 15V-24V fireworks ignition signal will trigger related firing sequences.
E5 Voltage Err		Battery voltage>15V or <10V for continuous 5s, machine stops running Possible fault: the battery is low.
E6 Tip Err		If The Machine Slant Over 45° , It Stops Running, System Will Report E6.

4.4 INTERFACE SETUP

Press "MENU" to switch through setup menu.

MENU	RANGE	EXPLANATION
Set DMX Address	1~512	DMX address setup
Angle Limit	Maxi. Angle: NO.1-NO.15	Restrict nozzle rotate angles: Set by "+" and "-", and confirm by "ENTER"
	Mini. Angle: NO.1-NO.15	

4.5 ADVANCED INTERFACE

Press "MENU" 3s enter advanced interface, press "MENU" to switch interface, press "MENU" 3s can back to main interface.



ITEMS	CONTENTS	DESCRIPTION
Drive Test	Motor	Swiveling and stop at target angle.
	Pump	Pump running 1s, if pressure reached the target value, the pump will not running.
	Ignite	Ignite 1s.
	Relief Valve	Release valve will be on and off for 3 times.
	Jet Valve1	Safety lock located at user mode, release pressure for 5s, jet valve will be on and off for 3 times.
	Jet Valve2	
	OFF	Test closed.
Ext Ignite	OFF / ON	Trigger through 15-24V fireworks ignitor signal.
Set Ext Sequence	1~88	Preset sequence triggered by fireworks ignitor.
Tilt Switch	OFF / ON	If The Machine Slant Over 45° , It Stops Running, System Will Report E6.
Mode Select	Normal Mode / Factory Mode	Factory mode is for test in factory only.
Head To Middle	OFF / ON	While the value of channel 1 is 0, the fire head will back to middle (Angle No.8) after finishing a sequence.
Default Parameter	OFF / ON	Reset default parameter settings.
Invert Mode	OFF / ON	When turn on this mode, all angles will run in mirror image
Motor Disabled	OFF / ON	When the motor fails and is saved, the device needs to be restarted to take effect. At this time, the position of the flame nozzle needs to be manually adjusted.
Language	English/Chinese	Language switch.

5 OPERATION GUIDE

5.1 SAFETY WARNING

This is the safety distance marking under calm / no-wind conditions.

Nozzle	Flame Height	Flame Height	Safety Distance	Safety Distance	Safety Distance
	min.	Max.	Control Side(a)	Audience Side(a)	Firing Direction(b)
00055 Nozzle	8m	10m	5m	5m	1-15m-(SF-180)-15m-



- 1、 1 to 15 is the firing angle of TORNADO FLAMER, Far Right is position 15, Middle is position 8, Far Left is position 1.
- 2、 Audience side and control side are indicated in above picture.
- 3、 Safety distances for TORNADO FLAMER are indicated in above picture. At least 15m in all projection directions, at least 5m to the other sides of the device..


NOTICE

In order to indicate correct direction, please place the top panel correctly.

5.2 SAFETY DISTANCE IN WINDY ENVIRONMENT

For Nozzle 00055:
 $a = 5 + v$; $b = 15 + v$
For example: when the wind speed is 3 m/s, and we use Nozzle 00055 on the TORNADO FLAMER, then the safety isolation zone in the control direction should be 8 m, and the safety distance in the firing direction should be 18 m.
When the wind speed > 8 m/s (wind force > level 5), use with caution.
When the wind speed > 17 m/s (wind force > level 8), stop use.

Nozzle	Flame Height	Flame Height	Safety Distance	Safety Distance	Safety Distance
00055 Nozzle	mini.	Max.	Control Side(a)	Audience Side(a)	Firing Direction(b)
	8m	10m	5m+v	5m+v	-15m+v- (SF-180) -15m+v-



5.3 FAST OPERATION GUIDE

Immediately upon receiving the machine, carefully unpack the carton, check the machine received in good condition. Ensure safety operation of machine, please do following below operation procedures when operate TORNADO FLAMER

1. Installation

The device can only be placed horizontally, if placed on truss, please locked with extra safety ropes.



2. Locate Safety Lock At TEST MODE

Before operate machine please locate safety lock at TEST MODE.
TEST MODE: operator can test the rotate of nozzle, but the fuel ejection function disabled, so there is no fuel eject and flames.
USER MODE: the device can generate flames normally. Please strictly follow the safety distance requirement, remove all human, animal or flammable objects in the danger area.



3. Fueling

Please fueling with high quality fuel according to requirement of this manual.



4. Power and DMX cable connection

Two kind of power supply optional:
1.110V/220V main power supply
12V battery power supply



5. Switch ON the machine

Please confirm safety lock located at TEST MODE before switch on the POWER ON/OFF.



6. Set DMX address

TORNADO FLAMER occupy 6 channels.
Detail information please refer to the table of page20-22.



7. Pressuriser

Host controller: Press "HEAT"
DMX console: switch DMX value of channel 6 to 50-200



8. Check device status in TEST MODE

Reconfirm safety lock located at TEST MODE before test. In this status, the nozzle will rotate, and igniter will activated, but there is no flame. When use DMX console to test the sequence, suggest to set CH1 at 128, so that nozzle stay at straight up position after each sequence.



9. Pressure Relief

Host controller: Press "HEAT" key
DMX console: switch DMX value of channel 6 to 0-49/201-255



10. Switch safety lock to USER MODE

Before switch to USER MODE, Please strictly follow the safety distance requirement, remove all human, animal or flammable objects in the danger area.



11. Pressuriser

Host controller: Press "HEAT"
DMX console: switch DMX value of channel 6 to 50-200

**12. Firing**

Set firing sequence Host controller: Press "FIRING" key
DMX console: switch DMX value of channel 3 to 254-255

**13. Pressure Relief**

Relief pressure when show finished or TORNADO FLAMER not use for a long period.
Host controller: Press "HEAT" key
DMX console: switch DMX value of channel 6 to 0-49/201-255

**14. Switch safety lock to TEST MODE**

Guarantee safety use for next time.


ON/OFF

**14. Power off**

Power off TORNADO FLAMER, tear down power cable and DMX cable, pack up the device when it is cooled down.

5.4 FIRING ANGLES

The firing angle for TORNADO FLAMER is $\pm 105^\circ$, from the Audience Side view, there are altogether 15 firing angles as below.



5.5 DRIVEN TIME

Time needed for the motor drive from NO.8 to relevant angle.

NO.	ANGLES	DRIVE TIME NEEDED
NO.1	-105°	170ms
NO.2	-90°	150ms
NO.3	-75°	130ms
NO.4	-60°	110ms
NO.5	-45°	90ms
NO.6	-30°	70ms
NO.7	-15°	50ms
NO.8	0°	0ms
NO.9	15°	50ms
NO.10	30°	70ms
NO.11	45°	90ms
NO.12	60°	110ms
NO.13	75°	130ms
NO.14	90°	150ms
NO.15	105°	170ms

For example for the motor drive from 0° to 45°, it need 90ms, when operator design a show to synchronize to music, this drive time must be calculated.

6 CONTROL OF TORNADO FLAMER

TORNADO FLAMER SF-180 has 88 preset sequences, operator use related channel DMX value or sequence No. to access certain sequence. Below, you can find sequence list and single ignitions.

6.1 SINGLE IGNITION SEQUENCE LIST

NO.	IGNITION ANGLE	DESCRIPTION	NOZZLE MOVEMENT	FIRING DURATION (FOR REFERENCE)	CH5 DMX REFERENCE VALUE
1	-105°	Single Ignition SHORT flame	Static	0.418s	3-5
2	-90°	Single Ignition SHORT flame	Static	0.395s	6-7
3	-75°	Single Ignition SHORT flame	Static	0.370s	8-10
4	-60°	Single Ignition SHORT flame	Static	0.344s	11-12
5	-45°	Single Ignition SHORT flame	Static	0.324s	13-15
6	-30°	Single Ignition SHORT flame	Static	0.303s	16-17

NO.	IGNITION ANGLE	DESCRIPTION	NOZZLE MOVEMENT	FIRING DURATION (FOR REFERENCE)	CH5 DMX REFERENCE VALUE
7	-15°	Single Ignition SHORT flame	Static	0.278s	18-20
8	0°	Single Ignition SHORT flame	Static	0.258s	21-22
9	15°	Single Ignition SHORT flame	Static	0.278s	23-25
10	30°	Single Ignition SHORT flame	Static	0.303s	26-28
11	45°	Single Ignition SHORT flame	Static	0.324s	29-30
12	60°	Single Ignition SHORT flame	Static	0.344s	31-33
13	75°	Single Ignition SHORT flame	Static	0.370s	34-35
14	90°	Single Ignition SHORT flame	Static	0.395s	36-38
15	105°	Single Ignition SHORT flame	Static	0.418s	39-40
16	-105°	Single Ignition LONG flame	Static	0.760s	41-43
17	-90°	Single Ignition LONG flame	Static	0.737s	44-45
18	-75°	Single Ignition LONG flame	Static	0.711s	46-48
19	-60°	Single Ignition LONG flame	Static	0.686s	49-50
20	-45°	Single Ignition LONG flame	Static	0.666s	51-53
21	-30°	Single Ignition LONG flame	Static	0.645s	54-56
22	-15°	Single Ignition LONG flame	Static	0.620s	57-58
23	0°	Single Ignition LONG flame	Static	0.599s	59-61
24	15°	Single Ignition LONG flame	Static	0.620s	62-63
25	30°	Single Ignition LONG flame	Static	0.645s	64-66
26	45°	Single Ignition LONG flame	Static	0.666s	67-68
27	60°	Single Ignition LONG flame	Static	0.686s	69-71
28	75°	Single Ignition LONG flame	Static	0.711s	72-73
29	90°	Single Ignition LONG flame	Static	0.737s	74-76
30	105°	Single Ignition LONG flame	Static	0.760s	77-79

6.2 STEP IGNITION SEQUENCE LIST:

NO.	IGNITION ANGLE	DESCRIPTION	NOZZLE MOVEMENT	FIRING DURATION (FOR REFERENCE)	CH5 DMX REFERENCE VALUE
31	Step from 1-15	SHORT flame Step sequence	L -> R	2.66s	80-81
32	Step from 15-1	SHORT flame Step sequence	R -> L	2.66s	82-84
33	Step 5>8>11	SHORT flame Step sequence	L -> R	0.92s	85-86
34	Step 11>8>5	SHORT flame Step sequence	R -> L	0.92s	87-89
35	Step 6>10	SHORT flame Step sequence	L -> R	0.75s	90-91
36	Step 10>6	SHORT flame Step sequence	R -> L	0.75s	92-94

NO.	IGNITION ANGLE	DESCRIPTION	NOZZLE MOVEMENT	FIRING DURATION (FOR REFERENCE)	CH5 DMX REFERENCE VALUE
37	Step 4>6>8>10>12	SHORT flame Step sequence	L -> R	1.27s	95-96
38	Step 12>10>8>6>4	SHORT flame Step sequence	R -> L	1.27s	97-99
39	Step 8>6>10>4>12	SHORT flame Step sequence	M>L>R>L>R	1.60s	100-101
40	Step 8>10>6>12>4	SHORT flame Step sequence	M>R>L>R>L	1.60s	102-104
41	Step from 1-15	LONG flame Step sequence	L -> R	7.78s	105-107
42	Step from 15-1	LONG flame Step sequence	R -> L	7.78s	108-109
43	Step 5>8>11	LONG flame Step sequence	L -> R	1.82s	110-112
44	Step 11>8>5	LONG flame Step sequence	R -> L	1.82s	113-114
45	Step 6>10	LONG flame Step sequence	L -> R	1.25s	115-117
46	Step 10>6	LONG flame Step sequence	R -> L	1.25s	118-119
47	Step 4>6>8>10>12	LONG flame Step sequence	L -> R	2.68s	120-122
48	Step 12>10>8>6>4	LONG flame Step sequence	R -> L	2.68s	123-124
49	Step 8>6>10>4>12	LONG flame Step sequence	M>L>R>L>R	2.88s	125-127
50	Step 8>10>6>12>4	LONG flame Step sequence	M>R>L>R>L	2.88s	128-130

6.3 WAVE SEQUENCE LIST:

NO.	IGNITION ANGLE	DESCRIPTION	NOZZLE MOVEMENT	FIRING DURATION (FOR REFERENCE)	CH5 DMX REFERENCE VALUE
51	Wave 5 -->11	Middle wave sequence	L -> R	1.87s	131-132
52	Wave 11-->5	Middle wave sequence	R -> L	1.87s	133-135
53	Big wave 1--15	LONG wave sequence	L -> R	4.08s	136-137
54	Big wave 15--1	LONG wave sequence	R -> L	4.08s	138-140
55	Wave 8-->1	Middle wave sequence	M -> L	2.09s	141-142
56	Wave 8-->15	Middle wave sequence	M -> R	2.09s	143-145
57	Wave 1-->8	Middle wave sequence	L -> M	2.31s	146-147
58	Wave 15-->8	Middle wave sequence	R -> M	2.31s	148-150
59	Wave 8-->11	SHORT wave sequence	M -> R	0.99s	151-152
60	Wave 8-->5	SHORT wave sequence	M -> L	0.99s	153-155
61	Wave 5-->8	SHORT wave sequence	L -> M	1.08s	156-158
62	Wave 11-->8	SHORT wave sequence	R -> M	1.08s	159-160

6.4 ADDITIONAL SEQUENCE LIST:

NO.	IGNITION ANGLE	DESCRIPTION	NOZZLE MOVEMENT	FIRING DURATION (FOR REFERENCE)	CH5 DMX REFERENCE VALUE
63	Step 3>13	SHORT wave sequence	L -> R	0.93s	161-163
64	Step 13>3	SHORT wave sequence	R -> L	0.93s	164-165
65	Step 3>13	LONG wave sequence	L -> R	1.63s	166-168
66	Step 13>3	LONG wave sequence	R -> L	1.63s	169-170
67	Step 8-13	SHORT wave sequence	M -> R	1.55s	171-173
68	Step 13-8	SHORT wave sequence	R -> M	1.55s	174-175
69	Step 8-13	LONG wave sequence	M -> R	3.24s	176-178
70	Step 13-8	LONG wave sequence	R -> M	3.24s	179-181
71	Step 8-3	SHORT wave sequence	M -> L	1.54s	182-183
72	Step 3-8	SHORT wave sequence	L -> M	1.54s	184-186
73	Step 8-3	LONG wave sequence	M -> L	3.24s	187-188
74	Step 3-8	LONG wave sequence	L -> M	3.24s	189-191
75	Step 3-13	SHORT wave sequence	L -> R	1.98s	192-193
76	Step 13-3	SHORT wave sequence	R -> L	1.98s	194-196
77	Step 2-14	SHORT wave sequence	L -> R	2.32s	197-198
78	Step 14-2	SHORT wave sequence	R -> L	2.32s	199-201
79	Step 8>5>11	SHORT wave sequence	M>L>R	0.93s	202-203
80	Step 8>11>5	SHORT wave sequence	M>R>L	0.93s	204-206
81	Step 5-11	SHORT wave sequence	L -> R	1.28s	207-209
82	Step 11-5	SHORT wave sequence	R -> L	1.28s	210-211
83	Wave 8-->13	Middle wave sequence	M -> R	1.70s	212-214
84	Wave 13-->8	Middle wave sequence	R -> M	1.70s	215-216
85	Wave 8-->3	Middle wave sequence	M -> L	1.60s	217-219
86	Wave 3-->8	Middle wave sequence	L -> M	1.60s	220-221
87	Wave 3-->13	LONG wave sequence	L -> R	3.06s	222-224
88	Wave 13-->3	LONG wave sequence	R -> L	3.06s	225-226
>89	8(0°)	Single Ignition LONG flame	Static	max. 8s	227-255

7 DMX CONTROL

CHANNEL 1	FUNCTION (Manual Angle setup)
0~255	(0~255) angle change from -105° to 105°, (128) is straight upward (0°)
CHANNEL 2	FUNCTION (Manual Speed setup)
0	Max Speed
1~254	Speed increase
255	Max Speed
CHANNEL 3	FUNCTION (Ignition ON/OFF)
0~253	Ignition OFF
254~255	Ignition ON
CHANNEL 4	FUNCTION (Firing Duration setup)
0/255	0 and 255 is permanent fire (8s is limit duration time)
1~254	1~254 is 10~2540ms duration time (Manual firing duration = DMX Value * 10ms)
CHANNEL 5	FUNCTION (Program sequence setup)
0~2	No preset sequence
3~255	Preset sequence., DMX value = 2 + Sequence No.*2.55 (ROUND OFF)
CHANNEL 6	FUNCTION (Mode setup)
0~49	Pressure Relief Mode (Emergency Stop)
50~200	Compression Mode
201~255	Pressure Relief Mode (Emergency Stop).

7.1 ANGLE SETUP

ANGLE NO.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
ANGLE	-105°	-90°	-75°	-60°	-45°	-30°	-15°	0°	15°	30°	45°	60°	75°	90°	105°
DMX VALUE	0	18	36	54	73	91	109	128	146	165	183	201	219	237	255

- 1.The first channel controls the firing angle. It defines to which angle the nozzle of TORNADO FLAMER move to. The angle can be chosen anywhere between -105° to +105° (DMX value 0 to 255).
- 2.The DMX value for angle of 0° is 127.5 (round up 128). Use this value, following formula can be used to calculate all other angles ∠ in degree. Please always note the prefix of the angle.

$$\text{DMX Value}=127.5+ (\angle \ast 1.2145)$$

7.2 CHANNEL 2 (CH2): SPEED SETUP

CH2: SPEED SETUP			
DMX VALUE	0	1-254	255
SPEED	Max Speed	Incremental of Speed	Max Speed

The second channel defines the rotate speed. It work together with Channel 1 for manual firing.

7.3 CHANNEL 3 (CH3): IGNITION ON/OFF

CH3: IGNITION		
DMX VALUE	0-253	254-255
SPEED	TORNADO FLAMER won't ignite	TORNADO FLAMER ignites

The third channel activates the actual ignition. If the DMX value of this channel higher than 253, the TORNADO FLAMER will ignite.

7.4 CHANNEL 4 (CH4): FIRING DURATION SETUP

CH4: MANUAL FIRING DURATION SETUP							
DMX VALUE	0	1	2	3		254	255
FIRING DURATION	Permanent	10ms	20ms	30ms		2540ms	Permanent

The fourth channel is the firing duration setup.
Below formula can be used to calculate the firing duration (ms):

$$\text{DMX Value}=t/10$$

7.5 CHANNEL 5 (CH5): PROGRAM SEQUENCE SETUP

The fifth Channel allows to firing a preset sequence. Three DMX values can be used for one of the programmed firing sequence from above sequence list (refer to above sequence list table).

Below formula can be used to calculate firing sequence:

$$\text{DMX Value} = 2 + \text{Sequence No.} \times 2.55$$

CH5: SEQUENCE LIST							
DMX VALUE	0~2	3~5	6~7	8~10	11~12		225~226
SEQUENCE NO.	N/A	1	2	3	4		88

7.6 CHANNEL 6 (CH6): MODE SETUP

The sixth channel is the working mode of pump.

When the safety lock located at TEST MODE, set DMX value between 50-200 to test the system. For safety, the device will not pressurize

When the safety lock located at USER MODE, the device pressurize activated by set DMX value between 50-200. The device can only make ignitions in Firing mode.

CH6: MODE SETUP			
DMX VALUE	0-49	50-200	201-255
MODE	Pressure Relief Mode	Firing Mode	Pressure Relief Mode

7.7 DMX CONTROL

7.7.1 EXAMPLE OF DMX CONTROL:

1. Set nozzle straight up

CH1 Angle = 128, CH2 Speed = 0, CH3 Ignition = 0, CH4 Firing duration = 0, CH5 Program sequence = 0, CH6 Firing mode = 50~200

2. Set preset Sequence No. 31

CH1 Angle = 128, CH2 Speed = 0, CH3 Ignition = 0, CH4 Firing duration = 0, CH5 Program sequence DMX value = 80, CH6 Firing mode = 50~200

3. Ignition

CH1 Angle = 128, CH2 Speed = 0, CH3 Ignition = 255, CH4 Firing duration = 0, CH5 Program sequence DMX value = 80, CH6 Firing mode = 50~200

NOTICE

After firing, the DMX value of CH3 must back to 0, before an ignition can be made again. CH1 determines the nozzle direction after firing.

7.7.2 EXAMPLE OF WAVE FIRING BY DMX CONSOLE

1. Set firing nozzle to the start point

CH1 Angle = 0, CH2 Speed = 255, CH3 Ignition = 0, CH6 Firing mode = 50~200

2. Set wave speed

CH1 Angle = 0, CH2 Speed = 50, CH3 Ignition = 0, CH6 Firing mode = 50~200

3. Set firing end point and ignition

CH1 Angle = 255, CH2 Speed = 50, CH3 Ignition = 255, CH6 Firing mode = 50~200

4. Firing Nozzle will firing and make movement from start point to end point.

NOTICE

After firing, The DMX value of CH3 must back to 0, before an ignition can be made again.

7.7.3 EXAMPLE OF FIRING WITH FIXED DURATION BY DMX CONSOLE

1. Set nozzle straight up

CH1 Angle = 128, CH2 Speed = 0, CH3 Ignition = 0, CH4 Firing duration = 0, CH6 Firing mode = 50~200

2. Set firing duration 1s

CH1 Angle = 128, CH2 Speed = 0, CH3 Ignition = 0, CH4 Firing duration = 100, CH6 Firing mode = 50~200

(Note: Firing duration = DMX value * 10ms [1s])

3. Firing 1s

CH1 Angle = 128, CH2 Speed = 0, CH3 Ignition = 255, CH4 Firing duration = 100, CH6 Firing mode = 50~200

NOTICE

After firing, The DMX value of CH3 must back to 0, before an ignition can be made again.

NO.	DMX VALUE
1	1
2	7
3	13
4	19
5	25
6	31
7	37

NO.	DMX VALUE
8	43
9	49
10	55
11	61
12	67
13	73
14	79
15	85
16	91
17	97
18	103

NOTICE

After firing, The DMX value of CH3 must back to 0, before an ignition can be made again.

1.To maintain the system in good performance and running status, it is recommended to running the device at least once per month.

2.Maintenance of the nozzle: Nozzle need to be cleaned up , and it is recommended that once every six months (depending on the environment and frequency of use). In the process of using the equipment, if the flame shape is seriously deformed or the fuel injection line is significantly deformed or coarsened, the nozzle should be removed immediately for cleaning.

3.Maintenance of the O-ring: If it is found that the O-ring of the nozzle is damaged or ageing when cleaning the nozzle, the O-ring should be replaced in time (material and size of O-ring: Fluoridated rubber O-ring, the outermost diameter is 14 mm, and the line diameter is 2 mm).



4.In order to lubricate the pipeline and pump it is highly recommended to add 10-20ml castor oil per 10L canister.

5.Software can be upgraded with download cable from SPARK FABRICA.

6.Switchable power input design, switchable between 110V and 220V as show below (voltage will show on it). The power supply is located on the side of the electric control, and you should remove the cover in order to change it.



8 HOW TO OPERATE FLAME MACHINE WITH CONSOLE CT-05

8.1 CT-05 INTRODUCTION

A newest digital console which can work with special effects, audio and video. Through serious networking protocol, it affords serious control, such as controlling spark machines remotely. This new console achieved more perfect sparking effect for wedding, content, sport events and meeting, etc.



8.2 SELECT FLAME MACHINE

After entering setting page and selecting "Flamer" from "Equipment Type", please press "Save" to save your setting. Caution: Flame machine's default channel on console is 6 channel, and the channel on flame machine also should be 6 channel.



8.3 SELECT SHOOTING SERIAL NUMBER

Enter File page and select shooting serial number 0-89.

NOTICE

Only when the shooting serial number is 89, the duration can be effective. The built-in shooting time 0-88 can not be adjusted, in addition, "height" and "density" are useless.



8.4 EDIT THE FILE

Press "HEAT" to start pressure machines, and press "FIRE" to start shooting.

NOTICE

When not using machines, please press "Heat" to cancel pressure and set machines to test mode to avoid accidents.



9 WARRANTY INSTRUCTIONS

Sincere thanks for your choosing TORNADO FLAMER SF-180, you will receive quality service from us.

The product warranty period is one year. If there are any quality problems within 7 days after shipping out from our factory, we can exchange a brand new same model machine for you.

We will offer free of charge maintenance service for machines which with hardware malfunction (except for the instrument damage caused by human factors) in warranty period. Please don't repair machine without factory permission.

Below situations NOT included in warranty service:

NOTICE

Damage caused by improper transportation, usage, management, and maintenance, or damage caused by human factors;

NOTICE

Disassemble, modify or repair products without SPARK FABRICA permission;

NOTICE

Damage caused by external reasons (lightning strike, power supply etc);

NOTICE

Damage caused by improper installation or use;

NOTICE

For product damage not included in warranty range, we can provide paid service.

* Invoice and warranty card are necessary when applying for maintenance service from SPARK FABRICA.

WARRANTY CARD

Product Name:		Serial No:	
Purchase Date:			
Tel:			
Address:			
Info.Feedback About The Problem :			
Actual Problem:			
Maintenance Detail:			
Service Engineer:		Service Date:	



CHANGSHA SPARK TECHNOLOGY ELECTRONICS CO., LTD

www.sparkfabrica.com marketing@sparkfabrica.com +86138 7585 1139